

INSTRUCTIONS – ~~ROLLER SHUTTER~~ WIFI HUB FOR ROLLER SHUTTERS



- 1- Download the app **HOMEMATE** from Apple Store or GooglePlay,
- 2- Create a Login/Sign Up,
- 3- Keep your WiFi login details on hand,
- 4- Plug the device to a power point – a red light ring should appear around the centre button,
- 5- Press and hold down the button for about 5 seconds until the red light starts flashing,
- 6- On your phone app click “ADD DEVICE”,
- 7- Select “SMART HUB” on the list,
- 8- Select “ALLONE PRO” and click NEXT,
- 9- Select your home WiFi and enter your password,
- 10- The light on the device should turn Blue. This means your device is connected to your WiFi. Here you will be able to edit the device’s name. Once complete press DONE,
- 11- Get close to the roller shutter that requires tuning to the app and have the correct roller shutter remote in the other hand,
- 12- On the main screen, select the box named “ALLONE PRO”,
- 13- Click on the ADD “+” symbol at the bottom right-hand corner,
- 14- Select Motors on the top left-hand corner,
- 15- Select “A-OK MOTOR” (first on the list),
- 16- Click Next,
- 17- Now, on the Roller Shutter Remote press and hold down the Stop Button (Centre Button) for 5 seconds or until the light on the remote stops flashing – the shutter should react with a slight movement,
- 18- On your phone app click “PAIRING” – the shutter should react with a slight movement – The device is able to respond to the operation, indicating the pairing was successful. Press “Response has been stored”. Only if there was response.

Your roller shutter should be working from your phone now. On the right top corner, you can click on settings and change the name of your roller shutter. On Device Type you can select Roller Shutter. With the app you will be able to set up a timer to close and open your roller shutter, change the picture on your screen and much more.